



Klipsch[®]

PRO-1000SW

РУКОВОДСТВО ПОЛЬЗОВАТЕЛЯ

РАЗМЕЩЕНИЕ


POSITIONNEMENT

UBICACIÓN PLATZIERUNG

POSIÇÃO

COLLOCAZIONE

布置



САБВУФЕР

ВЫРЕЗ


DÉCOUPER

SEPARAR


AUSGESCHNITTEN RECORTAR

RITAGLIARE

剪下



ШАБЛОН
GABARIT PLANTILLA SCHABLONE MODELO DIMA FORNITA 模板



СОЕДИНЕНИЯ


BRACHEMENTS

CONEXIONES ANSCHLÜSSE

CONNESSIONI

CONEXÕES

连接





УСТАНОВКА

УСТАНОВКА CONFIGURACI6N

УСТАНОВКА APPONTAMENTO

INSTALAÇÃO





設置



#10 1.5" САМОРЕЗЫ
(в комплекте)



ОКРАСКА

PEINDRE PINTAR MALEN PINTAR VERNIC 油漆



УХОД И ОЧИСТКА

ENTRETIEN ET NETTOYAGE CUIDADO Y LIMPIEZA PFLEGE UND REINIGUNG CURA E PULIZIA CUIDADOS E LIMPEZA 保养与清洁





Klipsch®

KEEPERS OF THE SOUND®

3502 WOODVIEW TRACE, INDIANAPOLIS, IN, USA

KLIPSCH.COM



1-800-KLIPSCH ©2015 KLIPSCH GROUP, INC. ВСЕ ПРАВА СОХРАНЕНЫ. KLIPSCH И KEEPERS OF THE SOUND ЯВЛЯЮТСЯ ЗАРЕГИСТРИРОВАННЫМИ ТОРГОВЫМИ МАРКАМИ KLIPSCH, GROUP INC. В США И ДРУГИХ СТРАНАХ.
ПОЛНОСТЬЮ ПОДЧИНЕННАЯ ДОЧЕРНЯЯ КОМПАНИЯ МЕЖДУНАРОДНОЙ КОРПОРАЦИИ VOXX.

V01-1019